

Product Manual of Action Camera Accessories

Quick Start Guide:

- Attach the chin mount to the helmet.
- Secure the action camera onto the mount.
- Adjust the camera to achieve the desired shooting angle.
- Ensure all connections are tight before use.

Warnings:

Safety Information:

- Keep the mount and camera dry.
- Store in a cool, dry place when not in use.

Service: Contact our store support for any issues.